



Einhell

CLASSIC

Cordless Grass- and Bush Shear

GC-CG 3,6 Li

Item No.: 3410455

Ident No.: 11027

Bar Code: 4006825607789

The GC-CG 3.6 Li cordless grass and shrub shear is a practical and compact tool which makes easy work of small cutting jobs on lawn edges, bushes and shrubs. The safety switch on the handle can be comfortably operated with one hand and prevents the tool from being switched on unintentionally.

Features & Benefits

- Safety switch - protects against uncontrolled switching on
- Grass cutting blade included - lawn edge care
- Including shrub shear blade - care of bushes and shrubs
- Simple and tool-free knife change
- Telescopic tube allows comfortable use in upright position
- Wheels for easy guidance

Technical Data

- Max. running time 60 min
- Charging time 3-5h
- Cutting width with grass shear knife 7 cm
- Cutting length with shrub cutting knife 10 cm
- Cutting thickness with shrub cutting knife 8 mm
- Spacing between teeth of shrub cutting knife 8 mm
- Accumulator 3.6 V | 1500 mAh | Li-Ion

Logistic Data

- Product weight 0.69
- Gross weight single packaging 1.81 kg
- Dimensions single packaging 900 x 160 x 90 mm
- Pieces per export carton 8 Pieces
- Gross weight export carton 15 kg
- Dimensions export carton 925 x 325 x 300 mm
- Container quantity (20"/40"/40"HC) 2352 | 4928 | 5632

