





















FIELDMANN[®]
Home & Garden Performance



FZO 4001

FZO 4001 • EN: Garden Tidy Cart • CZ: Zahradní vozík • SK: Záhradný vozík • PL: Wózek ogrodowy • HU: Kerti kocsi • RU: Садовая тележка • LT: Sodas vežimėlio
 • EN: INSTALLATION INSTRUCTIONS • CZ: POKYNY K INSTALACI • SK: POKYNY NA INŠTALÁCIU • PL: ZALECENIA DOTYCZĄCE INSTALACJI • HU: TELEPÍTÉSI UTASÍTÁSOK • RU: ИНСТРУКЦИИ ПО УСТАНОВКЕ • LT: RENGIMO INSTRUKCIJOS



①	 L 1×	 R 1×
②		
③		1×
④		1×
⑤		2×
⑥		2×
⑦		
⑧	 L 1×	 R 1×

⑨		1×
⑩		1×
⑪		2×
⑫		1×
⑬		2×
⑭		1×
⑮		4×
⑯		